

RISA Standalone Install Instructions - Quick Reference

This guide is intended as a quick reference for Standalone Installations of RISA programs. For any trouble-shooting issues or problems that are outside the scope of this document please refer to the complete Standalone Installation Instructions . It can be found on our website here: <http://www.risa.com/documents/pdfs/Stand Alone Installation Instructions.pdf>

1. Download the RISA Software installation from the links provided in your upgrade email and save them to your computer.
2. Double click on the exe you downloaded to start the installation process.
3. Follow the on-screen instructions for the installation.
4. (Standalone Perpetual Users Only) If you are prompted to remove your USB key, then do so. Plug the key back after you have clicked Finish in the installation window.
5. (Subscription Users Only) If you are prompted to enter an Activation Code please do so from the RISA e-mail.
6. Open the RISA programs you installed.
7. (Standalone Perpetual Users Only) Upon opening the program you will be prompted to enter the RUS Password(s) from the upgrade e-mail.
 - NOTE: If you have multiple standalone licenses you will need to enter the RUS Password that matches the Key ID listed in the dialogue box after opening the program.
8. (Subscription Users Only) The program should use the internet to use a subscription license for your account.